

Thank you for purchasing the Rexall™ Flex Tip Digital Thermometer. To correctly utilize all the advantages of this product, please familiarize yourself with these operating instructions before using the thermometer for the first time. Keep the instructions in a safe place for future reference.

SAFETY INFORMATION:

- High, prolonged fever requires medical attention, especially for young children. Please contact your physician should this occur.
- This thermometer contains small pieces that can pose a choking hazard. Do not allow children to take their own temperatures unattended.
- Keep battery away from children, harmful if swallowed.
- Do not open the thermometer except to replace the battery.
- To avoid damage to the probe, do not bend beyond a 45° angle.
- Use of a probe cover may result in a 0.1°C / 0.2°F discrepancy from actual temperature.
- Do not boil probe to disinfect.
- Do not store in direct sunlight or in areas of extreme heat.

HOW TO TAKE A TEMPERATURE:

1. Select Oral, Axillary (Underarm) or Rectal as your measurement site based on each individual. Clean thermometer with soap and water prior to use.
2. Push the operating button located beside the display window. The thermometer will beep and the display will read: **000.0**. This is a function check indicating that the unit is working properly. Should there be a reading in the memory it will then appear. Immediately after 37.0°C / 98.6°F will appear then, **LO** with the °C/F flashing and the "M" gone, will indicate that the thermometer is ready for use.

IMPORTANT: **LO** does not refer to the battery level.

3. While taking a temperature, the °C/F symbol flashes as long as the temperature increases.
4. A beep will sound for 10 seconds indicating that the peak temperature has been reached. If the temperature is 37.8°C / 100°F or higher rapid beeps will sound indicating a fever.

NOTE: The LCD will display "LO°C" if the measurement taken is below 32.0°C / 90°F. It will display "HI°C" if the measurement is above 42.9°C / 109.9°F.

5. To prolong the life of the battery, turn the thermometer off after each use by pressing the operating button briefly, otherwise the unit will turn off automatically in approximately 10 minutes.
6. To switch the thermometer from °C to °F, press and hold the operating button for 2 seconds when the thermometer is off. The thermometer will turn on and either °C or °F will be displayed.

ORAL USE:

- Do not drink hot or cold fluids, exercise, smoke or perform other activities prior to a measurement. These actions will raise or lower temperature readings when compared to your normal, average temperature. The mouth should remain closed for up to 5 minutes before attempting a reading.

- Place the probe tip well under the tongue and wait until a beep is heard. Instruct children not to bite down on the probe.

AXILLARY (UNDERARM) USE:

- Wipe underarm with a dry towel.

- Place the probe tip in the hollow of the armpit and bring arm down against the body and wait until a beep is heard.

RECTAL USE:

- Commonly used for babies, young children or when it is difficult to take an oral or axillary (underarm) temperature.
- Lubricate the thermometer with a water-soluble personal lubricant or petroleum jelly.
- Gently insert the probe tip no more than 1.3 cm or 1/2 inch into the rectum, and wait until a beep is heard.

Do not force the tip into the rectum if resistance is encountered.

WHAT IS "NORMAL" BODY TEMPERATURE?

"Normal" body temperature varies from person to person and changes according to time of day and body location. The following table shows the temperature ranges:

Use	Fever Temperature?	Temperature Ranges
Rectal*	Over 38°C / 100.4°F	36.3°C - 38°C / 97.3°F - 100.4°F
Oral (mouth)*	Over 37.8°C / 100°F	36.1°C - 37.8°C / 97°F - 100°F
Axillary (underarm)*	Over 37.2°C / 99°F	35.2°C - 37.2°C / 95.4°F - 99°F

*Fever definitions according to the American Medical Association

IMPORTANT: It is recommended to measure the body temperature when healthy to establish the specific "normal" temperature.

MEMORY RECALL:

This thermometer has a memory which recalls the last temperature taken. To obtain this information, with the thermometer off, press the operating button. The screen displays **000.0** then the last measurement which will be deleted after the next temperature is taken.

CLEANING AND DISINFECTING:

Before and after each use, clean the thermometer with warm soapy water and a soft cloth. Disinfect using a cotton ball moistened with alcohol. Never immerse in hot water or in harsh cleaning solutions.

CHANGING THE BATTERY:

When the **■** appears on the display, the battery is exhausted and needs replacing. Remove the battery compartment lid located at the top of the thermometer and discard the old battery. (See Figure 1) Insert a new equivalent battery (LR41, 1.5V). Ensure the battery is correctly positioned with the "+" facing down or towards the back of the unit. Replace battery compartment lid.




Figure 1

SPECIFICATIONS:

Temperature Range:	32°C to 42.9°C (90°F to 109.9°F)
Accuracy:	±0.1°C, 35.5°C to 42°C (±0.2°F, 95.9°F to 107.6°F) ±0.2°C under 35.5°C or over 42.0°C (±0.4°F under 95.9°F or over 107.6°F) at ambient temperature of 18°C to 28°C (64.4°F to 82.4°F)
Operating Environment:	Temperature: 5°C to 40°C (41°F to 104°F) Relative humidity: 15% to 95%
Storage and Transportation Condition:	Temperature: -20°C to 55°C (-4°F to 131°F) Relative humidity: 15% to 95%
Battery Type:	1 x 1.5V battery type LR41
Battery Life:	Approx. 200 hours



Read the instruction manual carefully before using this device, especially the safety instructions, and keep the instruction manual for future use.



Type BF Applied part



Batteries and electronic devices must be disposed of in accordance with the locally Applicable regulations, not with domestic waste.

IP22: Protected against solid foreign objects of 12.5 mm diameter and greater. Protected against vertically falling water drops when the device is tilted up to 15°.

LIFETIME WARRANTY:

This product is warranted to be free from defects in material or workmanship for the life of the original owner. It will be repaired or replaced without charge upon receipt of the unit prepaid with \$5.00 to cover handling, packaging and return postage to the address below.

Quality Assured / Qualité Assurée



Manufactured for / Fabriqué pour :

Rexall Pharmacy Group Ltd.

Mississauga, ON L4Z 1R9 ©2017

www.Rexall.ca

by / par: Thermor Ltd.

16975 Leslie Street, Newmarket, ON L3Y 9A1